



Tools Required



Light Source



Fixture Height Adjustable 20" to 65"

⚠ Warnings and Cautions

Turn off the electricity at the circuit breaker before installation. Consult a licensed electrician if in doubt about installation.


Turn off power to the fixture and allow the bulbs to cool before replacing.

Package Contents

Preparation: Identify and inspect all parts before beginning the installation.

Missing or damaged parts? Contact your original place of purchase.

PARTS BAG




A Crossbar Assembly
x 1




B Outlet Box Screw
x 2




C Wire Connector
x 3



D Fixture Chain
x 1



E Ceiling Canopy
x 1



F Fixture Loop
x 1


G Shade
x 1

H Socket Assembly
x 1

Table of Contents

Shade & Socket Assembly	Crossbar Assembly	Fixture Chain	Wiring	Ceiling Canopy	Bulb
STEP 1	STEP 2	STEP 3	STEP 4	STEP 5	STEP 6


STEP 1



STEP 2


1

Step 1
Install crossbar assembly




2

Step 2 - 3
Test fitting ceiling canopy to nipple




3



STEP 3


1

Step 1
Adjust fixture chain length




2

Step 2 - 3
Install Fixture Chain




3




STEP 4

1


Step 1
Feed the fixture wires through the loop



2



STEP 5



STEP 6

