

## INSTALLATION INSTRUCTION / INSTRUCCIONES DE INSTALACIÓN

### PARTS ENCLOSED / COMPONENTES INCLUIDOS

MOUNTING BRACKET - 1 PIECE



SOPORTE DE MONTAJE - 1 PIEZA

PLASTIC ANCHOR - 2 PIECES



ANCLAJE DE PLÁSTICO - 2 PIEZAS

MOUNTING SCREW - 2 PIECES



TORNILLO DE MONTAJE - 2 PIEZAS

### STEP/ PASO

1. MEASURE AND MARK THE DESIRED LOCATION.
2. DRILL TWO 1/4 HOLES INTO THE WALL AT THE MARKED LOCATION.
3. INSERT 2 PLASTIC ANCHORS INTO THE HOLES WHEN APPLYING TO SHEETROCK OR OTHER HARD SURFACES, ALTERNATIVELY, JUST DRILL A PILOT HOLE INTO THE WOOD TO HELP START THE SCREW.
4. INSERT THE SCREWS WITH MOUNTING BRACKET ON THE WALL.
5. ATTACH BATH FIXTURE ONTO MOUNTING BRACKET.
6. TIGHTEN THE SET SCREW UNTIL THE FIXTURE IS SECURE.

1. MIDA Y MARQUE LA UBICACIÓN QUE DESEE.
2. TALADRE DOS ORIFICIOS DE 1/4" EN UBICACIÓN MARCADA EN LA PARED.
3. INSERTE 2 TACOS DE PLÁSTICO EN LOS ORIFICIOS SI HACE LA INSTALACIÓN EN UNA PARED DE YESO U OTRA SUPERFICIE DURA. ALTERNATIVAMENTE, TALADRE UN ORIFICIO PILOTO EN LA MADERA PARA COMENZAR A ATORNILLAR EL TORNILLO.
4. INSERTE LOS TORNILLOS CON EL SOPORTE DE MONTAJE EN LA PARED..
5. COLOQUE LA BARRA DE BAÑO EN EL SOPORTE.
6. APRIETE EL TORNILLO DE FIJACIÓN HASTA QUE LA BARRA ESTÉ SEGURA..

