## **LED Vanity**

## START FROM HERE

- Make sure power is completely off at the fuse box.
- Have your fixture installed by a qualified licensed electrician
- · Prepare everything in a clear area.
- Wear gloves at all times during this installation.
- · Read instructions carefully before you start assembly.
- Keep this instruction sheet for future reference.

Technical Support: 1-877-452-6858

## Please Note:

• For dimming, a TRIAC type of dimmer is required.

- 1. Remove the fixture from its original packaging. Next, remove the backplate (1e) within the canopy (2a) by removing the screws (2b). Attach the crossbar (1c) to the electical junction box (1a) with screws (1d). Make sure the wires (1b) from the junction box pass through the hole in the backplate (1e). Attach the backplate (1e) to the crossbar by using the threaded rod, nut and washer (1f). Make sure to reinforce the wood behind the drywall for extra support and use the woodscrews and anchors (1h) to secure the backplate (1e) and bracket (1g) to the ceiling. Connect all wires (1b) correctly black to black "L", white to white "N" and the ground wire with provided marrettes from the hardware package.
- 2. You are now ready to mount the canopy to the backplate and bracket. Align the bracket (1g) to the holes inside the canopy (2a) and secure with two screws. This will secure the canopy to the backplate and bracket.
- **1** You have now completed the installation of your fixture, enjoy.



