

## **ASSEMBLING & INSTALLATION INSTRUCTIONS**

2284 2384 2388

The drawing shown may not exactly match the product enclosed. However, the installation instructions do apply to this product.

FIG.1

## 1. Shut off the power at the circuit breaker and remove old fixture, G Fixture Fixture Wire Ground Wire Supply Supply Ground Wire Wire F(No included) FIXTURE C FIXTURE C FIG.2 WIRES WIRES WIRES Black or White or Bare Smooth Ribbed Copper (Ground) HOUSE HOUSE HOUSE WIRES WIRES WIRES Green or Bare White Black(Hot) (Neutral) Copper(Ground) Thank you for purchasing a LIVEX product. Need assistance with parts or assembly? Please call customer service at: 800-761-8056 Or visit us on-line at: WWW.LIVEXLIGHTING.COM

©COPYRIGHT ALL RIGHTS RESERVED. LIVEX LIGHTING.INC.

DOC20161002384

2. Carefully unpack your new fixture and lay out all the parts on a clear area. Take care not to lose any small parts necessary for installation.

ATTENTION! COUPER LE COURANT AU FUSIBLE OU UN DISJONCTEUR.

WARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER.

3. Put the candle sleeve(G) over the lamp holder.

ASSEMBLING THE FIXTURE (Fig.1)

including the single bar.

- 4. Install the light bulbs (No Included) in accordance with the fixture's specifications. NOTE: DO NOT EXCEED THE MAXIMUM WATTAGE RATING!
- 5. Attach the pipe thread(C) into the shade of the lamp body(D), aligning the box top center screw hole with the pipe thread, by turning it clockwise until tight. Attach the cove (B) to the lamp body(D), then lock it securely with the loop(A).
- 6. Attach the assembly lamp body onto the post (F, no included) and lock it securely with the screws (E).

## **CONNECTING THE WIRES (Fig.2)**

- 1. Connect the electrical wires as follows. Connect the Black wire from the fixture to the black house (hot) Wire. Connect the white wire from the fixture to the white (neutral) house wire. Make sure all wire nuts are secured. You may wrap the connections with electrical tape. If your outlet box has a ground wires (green or bare copper) connect fixture's ground wire to it. Otherwise attach the bare copper fixture wire to the green ground screw on the mounting plate.
- 2. Tuck the wire connections neatly into the post.

Your installation is now complete. Return power to the junction box and test the fixture.