

# ASSEMBLY INSTRUCTIONS FOR #51950



## IMPORTANT

TURN OFF THE POWER AT THE MAIN FUSE OR CIRCUIT BREAKER BOX BEFORE STARTING INSTALLATION

CAREFULLY UNPACK AND IDENTIFY ALL PARTS BEFORE ASSEMBLY. BULBS ARE NOT INCLUDED

- 1.) Attach cross bar (A) to j-box using customer provided screws.
- 2.) Wire electrical wires (D) as per local electrical codes.
- 3.) Secure canopy (C) to cross bar (A) by screwing canopy nuts (E) onto cross bar screws (B).
- 4.) Place cork washer (G) then shade (H) onto threaded socket (F) and secure with uno ring (I).



*"A Commitment to Excellence in Lighting and Service"*

CALL OUR CUSTOMER SERVICE DEPARTMENT AT 1-800-222-4009

MONDAY - FRIDAY 8:00 a.m. - 6:00 p.m. ET

visit us on the web at [www.meyda.com](http://www.meyda.com)