

Replace swivel to be loop system (Fig. 3)

1. Un thread nut (E4), then remove lock washer (E3), flat plate (E2), swivel (E1) and rod (G) from canopy (E).
2. Attach one loop (O) to the other loop (O) by using quick link (P).
3. Place loops (O) over canopy (E), then place flat plate (E2) and lock washer (E3) onto protruding all thread at top of loop (O), securing with hex nut (E4).
4. Install loops (O) onto top of rod (G).

