

Assembly Instruction Sheet #IS-ANW8603EK For Style ANW8603EK

Please go to www.quoizel.com for product cleaning tips. Go to the Care + Maintenance selection. Tools Required: Flathead screwdriver, Phillips screwdriver, pliers, wire cutters, wire strippers, electrical tape, safety glasses. Light Source: (3) Medium Base Vintage Bulbs 60W (provided), Maximum 100W Estimated Assembly Time: 30-45 minutes Preparation: Identify and inspect all parts before beginning installation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fixture. Contact customer service for replacement parts. A Warnings and Cautions Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt. These instructions are provided for your safety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation. Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal. Package Contents **STEP 2 - Wire Connections** Vintage Bulb D x 3 A. Wrap bare or green ground wire around green ground screw on the crossbar, no less than 2 inches from the end of the wire. Tighten the green ground screw. Lock Shade Е B. Use standard wire connectors (not included) to make all wire R Screw х3 connections. Twist connectors until wires are tightly joined together. x 2 Wrap each connection with approved electrical tape and carefully stuff all the connected wires into the Outlet Box. Lock Inner Backplate Screw А White wire x 1 x 9 White wire from outlet box from fixture Black wire Black wire from from fixture outlet box (or Red) Fixture Body С Bare, or Green x 1 Ground wire Ground wire from Fixture from outlet box Green Ground Screw STEP 1 - Install Inner Backplate and Fixture Body Figure 2 on the Crossbar A. Pass the supply wires through Inner Backplate (A). Attach Inner **STEP 3 - Install Shades and Bulbs** Backplate (A) to Outlet Box with the head of Green Ground Screw С facing you. Secure it with Outlet Box Screws (not included). Tighten A. Place Shade (E) over the Cup, line until snua. up the mounting hole on the Cup B. Race all supply wires through the Inner Backplate (A) as shown. Cup and the hole on the Shade (E), Refer to Step 2 for wiring connections. secure by threading the Lock C. Attach Fixture Body (C) over Inner Backplate (A) and secure with 0 Screw (F) onto the mounting hole. Lock Screws (B). Tighten until snug with screwdrivers. F Hand tighten until sung. B. Insert bulbs onto sockets and Ó. screw snugly into place. ĩĩ Your fixture is now assembled and Outlet Box ready to use. Enjoy! Е Figure 3 1 D B Figure 1 Thank you for purchasing a Quoizel product. Need assistance with parts or assembly? Call Quoizel customer service at 1-800-645-3184 or visit us on-line at www.quoizel.com Released Date: 2018-01-27 © 2018 Quoizel Inc. 1of2

