

ASSEMBLY INSTRUCTIONS FOR YOUR

Jonathan Adler MILANO KINETIC CHANDELIER

IMPORTAN T SAFETY INSTRUCTIONS:

- * These instructions are provided for your safety. It is very important that they are read completely before beginning the installation of your fixture.
- * WE STRONGLY RECOMMEND INSTALLATION BY A LICENSED ELECTRICIAN.
- * For your safety, a junction box rated for fixtures OVER 100 LBS must be used with this fixture. Be sure to follow manufacturer's instructions when installing a junction box.
- * If any special control devices are used with this fixture, follow the instructions carefully to assure full compliance with N.E.C. requirements. If there are any questions, contact a qualified electrical contractor.
- * This fixture is U.L. rated for dry locations.

ASSEMBLY INSTRUCTIONS:

- 1. SHUT OFF THE MAIN ELECTRICAL SUPPLY AT FUSE BOX/ CIRCUIT BREAKER.
- 2. Remove all parts from carton. Do not throw away any parts.
- 3. Remove cross bar (A) from hang straigtht (F) by unthreading tube (C) from hang straight (F). Affix cross bar (A) (including threaded tube (C) to ceiling outlet box using mounting screws (B) provided.
- 4. Measure desired drop for fixture to hang and add/remove extension tubes (I). Guide wiring through extension tubes before threading tubes together. **ADD/REMOVE EXTENSIONS: (Un)Thread the threaded nipple of one extension into the threaded opening of the next extension. Make sure wiring is pulled tight when threading extensions together to prevent damage to the wire**
- 5. Connect hang straight (F) and loop (H) using quick link (G).
- 6. Thread bottom extension tube (I) onto the threaded tube (J).
- 7. Lift fixture to ceiling outlet box. Guide wiring and safety cable through threaded tube (C). Thread hang straight (F) onto threaded tube (C).
- 8. Guide safety cables exiting canopy (D) through the opening in the cross bar (A) and into ceiling outlet box. From above the ceiling outlet box, loop safety cables around an appropriate load bearing structure. Use cable lock to secure position of cable.
- 9. To install cable lock, remove hex nuts and lock nut from U-bolt. Place U-bolt over looped safety cable and slide lock nut over U-bolt. Loop the loose end of the safety cable around the lock nut two times as shown in diagram. Re-attach hex nuts to U-bolt to secure the position of the cable lock.
- 10. Cut the cord to the desired length to make electrical connections. Note: At least 8 inches of wire is needed to make proper electrical connections.
- 11. Make proper electrical connections described in steps 12 14. A LICENSED ELECTRICIAN IS RECOMMENDED.
- 12. Attach ground wire from fixture (green or silver in color) to ground wire from outlet box. Fasten wires together with wire nut (L) and tightly wrap connection with electrical tape.
- 13. Attach hot wire from fixture (black in color or smooth side of wire) to hot wire from outlet box. Fasten wires together with wire nut (L) and tightly wrap connection with electrical tape.
- 14. Attach neutral wire from fixture (white in color or ribbed side of wire) to neutral wire from outlet box. Fasten wires together with wire nut (L) and tightly wrap connection with electrical tape.
- 15. Carefully push wire connections back into the ceiling outlet box.
- 16. Slide canopy (D) up extension tubes (I) and hold firmly against ceiling. Slide collar (E) up extension tubes (I) and thread onto hang straight (F), securing canopy (D) against ceiling.
- 17. Install (8) 60W MAX Type G, medium base bulbs into sockets (K).
- 18. Reconnect main electrical supply from the fuse box/ circuit breaker and test the fixture.



ASSEMBLY INSTRUCTIONS FOR YOUR

Jonathan Adler MILANO KINETIC CHANDELIER

