



ASSEMBLY INSTRUCTIONS

1. Carefully unpack and identify all parts referring to illustration for parts identification.
2. Turn the power to the installation point OFF.
3. Install the cylinder (1) onto the coupling (2).
4. Assemble the rods (4) together using the nipple (3) Attach the bottom end of rods (4) onto coupling (6). Attach the other end to loop (5).
5. Install the crystal (8) onto the base (9) with the screw (10), securing with tool (11).
6. Refer to the additional installation instructions included with the product for wiring and installation.
7. Restore power to the installation point and retain this sheet for future reference.