



ASSEMBLY INSTRUCTIONS

1. Carefully unpack and identify all parts referring to illustration for parts identification.
2. Turn the power to the installation point OFF.
3. While threading wire through, assemble the rods (4) together using the nipples (3). Attach the bottom end of rods (4) into the coupling (11) until hand tight.
4. Secure the loop (5) onto the top of rods (4).
5. The cable affixed with L + label on the LED lighting power cable is connected to the cable affixed with L + label on the specific outlet cable, The N- label cable affixed to the LED lighting power cable is connected to the N- label cable affixed to the specific outlet cable of the clip.
6. Refer to the additional installation instructions included with the product for wiring and installation.
7. Use the quick link to connect the loop (5) to the loop on the canopy (1) and twist the locking mechanism to secure.
8. Insert the acrylic rod (6) into the arm (9). Align the hexagon socket screw (7) with the hole (10) on the acrylic rod. Secure the acrylic rod (6) to the arm (9) by tightening the hexagon socket screw with the hexagon wrench (8).
9. Restore power to the installation point and retain this sheet for future reference.