



- 1. Carefully unpack and identify all parts referring to illustration for parts identification.
- 2. Turn the power to the installation point OFF.
- 3. Install the mounting bar (2) to the Outlet Box (1) with screws (5), and then reinforce the mounting bar (2) to the ceiling with wood screw (4), and flat washers (3).
- 4. While threading wire through the rods (12), assemble the rods together using the nipples (11). Attach the bottom of the rods (12) into the coupling (13) until hand tight.
- 5. Connect the fixture body (18) to fixture body (14) using the hook (15).
- 6. Use quick link to connect loop (10) to the loop on the canopy (7) and twist the locking mechanism to secure.
- 7. Secure the Canopy (7) onto the Screw (6) using the Knurled Nut (8) and the Ball Nut (9).
- 8. Install the Natural Crystal (17) onto the fixture body (14) and fixture body (18) with the screw (16).
- 9. Restore power to the installation point and retain this sheet for future reference.