

ASSEMBLY INSTRUCTION FOR L72385

1. FASTEN TUBE A ONTO LAMP BASE
PULL EXCESS CORD THROUGH THE BASE YOU ASSEMBLE THE TUBES.
2. FASTEN TUBE B ONTO TUBE A
3. FASTEN TUBE C ONTO TUBE B
4. FASTEN TUBE D ONTO TUBE C
5. PLACE SHADE ONTO SOCKET SCREW RING ONTO SOCKET
6. SCREW BULB INTO SOCKET, BULB (MAX 60W) NOT INCLUDED

IMPORTANT SAFETY INSTRUCTIONS

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK .THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF THE PLUG DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY INSERTED . DO NOT ALTER THE PLUG.

