

## **ASSEMBLY INSTRUCTIONS**

## STYLE# 21955

## Careful unpack all lamp parts from the carton.

- 1. Take the lamp carefully out of the Carton, and place it on a flat surface.
- 2. Be sure the power to the installation point is power off
- 3. Thread the **coupling** into the **rods**.
- 4.Thread **Stem** into the **coupling** underside of the scoket cluster, Hand tigthen until sung.
- 5.Place the Ceiling Canopy over the Mounting Screws and thread Mounting Balls onto the Mounting Screws to secure it, Hand tighten until sung.
- 6.Located the following components over the end of the stem in turn Diffuser, Rubb washer, Flat washer.
- 7. Thread the **Hex Nut** onto the end of the **Stem** and tighten until sung to secure the above parts, Proceed to thread **Finial** onto the end of the **Stem** and hand tighten until snug.
- 8.Install bulbs (not included).See label located at socket area for type and maximum allowed wattage.

## IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug ( one blade is wider than the other ) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to defeat this safery feature.

