

TOB2005

ASSEMBLY & INSTALLATION GUIDE

WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN.

WARNING * SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION.**

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

1. Attach safety steel wire and safety cable to lock nut follow detail steps on illustration.
2. Open bottom frame (F) of lantern box (D) by removing screw (G).
3. To install the glass panel to each section, insert one side of glass panel against spring tab, and secure the opposite side of glass panel by the location tabs. For bottom frame (F), just insert glass panel as shown in illustration.
4. To detach mounting plate (A) and the rod (B) from lantern box (D) by unscrewing the decorative screws (E) in counter-clockwise direction.
5. Position the mounting plate (A) diagonally so that the holes of mounting plate (A) and outlet box are aligned. Tighten the mounting plate onto the outlet box with screws (C) provided.
6. Attach ground (chrome) fixture wire to ground wire from the outlet box (usually green or copper in color), and fasten together with a plastic wire connector. Tightly wrap the wire connector with electrical tape so the end of the connector is sealed.

IT IS IMPERATIVE THAT THE OUTLET BOX IN YOUR HOME BE PROPERLY GROUNDED.
7. Connect neutral (white) fixture wire to neutral (usually white) wire from the outlet box. Fasten both wires together with a plastic wire connector and tightly wrap the wire connector with electrical tape.
8. Repeat the procedure with the hot (black) wires. Always make sure that no wire strands are left outside the connectors.

DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.
9. Gently push lantern box (D) onto the outlet box, letting rods (B) pass through the holes on the back plate of lantern box (D), and secure with decorative screws (E).
10. Insert light bulbs into sockets. Close bottom frame (F) and secure with screw (G).

