

Hall Wide hanging Lantern Item # S 5797

WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN.

WARNING *** SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION.

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

- 1. Carefully remove all parts from the carton.
- 2. Insert light bulbs (not included) into sockets.
- 3. Remove metal tabs (M) by removing screws (L), install glass panels (K) to each frame of lantern box (J) and secure with metal tabs (M) and screws (L).
- 4. Feed the wires through the connection rod (H), connector (G) and connection rod (F).
- 5. Hook connection rod (H) to top loop (I).
- 6. Screw connector (G) onto the top nipple of connection rod (H) by turning in a clockwise direction until tight.
- 7. Thread the bottom nipple of connection rod (F) into the connector (G) by turning in a clockwise direction until tight.
- 8. Unscrew canopy collar (E), slide canopy collar (E) and canopy (D) on connection rod (F).
- 9. Attach mounting strap (A) to ceiling outlet and secure with mounting screws (C) provided.
- 10. Hook connection rod (F) to mounting loop (B).
- 11. Attach the bare copper ground wire from the fixture to the ground junction box wire (usually green or copper), fasten together with a plastic wire connector. Tightly wrap the wire connector with electrical tape. Be sure no wire strands are exposed. IT IS IMPERATIVE THAT THE OUTLET BOX IN YOUR HOME BE PROPERLY GROUNDED.
- 12. Connect neutral wire from fixture (ridged, molded wire) to the neutral wire from the junction box (usually white). Fasten both wires together with a plastic wire connector and tightly wrap the wire connector with electrical tape. Be sure no wire strands are exposed.
- 13. Connect the hot wire from the fixture (smooth wire) to the hot wire (usually black) from the junction box. Fasten both together with a plastic wire connector and wrap the connection with electrical tape. DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OTHERWISE SAFETY WILL BE COMPROMISED.
- 14. Tuck the wire connections neatly into the ceiling outlet box.
- 15. Slip canopy (D) to the affixed mounting strap (A) and secure with canopy collar (E).
- 16. Restore power and test fixture. Installation is complete.

*** Clean with a dry, soft cloth only. Use no harsh abrasives or chemical agents.

VISUAL COMFORT & CO. Est. 1987