## IN11326AGY INSTALLATION INSTRUCTIONS

1500 Cherokee Parkway, Suite 100, Acworth, GA 30102 Phone: (866) 845-5451. Fax: (866) 816-6165 www.acclaim-lighting.com



Please read carefully and save these instructions as you may need them a later date.

## **CAUTION**

Turn off the main power at the circuit breaker before installing the fixture, in order to prevent possible shock.

## **GENERAL**

All electrical connections must be in accordance with local and National Electrical Code (N.E.C) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustration.

## **ASSEMBLY AND INSTALLATION**

- 1. Use the quick links to connect the hooks between the long hung /short hung rods on the two tiers.
- 2. Use the nipple, washer, and hex nut to attach the mounting bar to the outlet box and secure using the 2 mounting screws.
- 3. Use two quick links at both ends of chain to link the fixture loop to the chain, and then the chain and top loop.
- 4. Lower the canopy onto the top nut and pass the top loop through canopy.
- 5. Make wire connections:
  - ---The ridged wire (unmarked) from the fixture to white wire from power source.
  - ---The smooth wire (marked) from the fixture to black wire from power source.
  - ---Attach the ground wire to cross bar with a green screw.
- 6. Place the canopy over the outlet box and secure with top nut.
- 7. Install bulbs: (Bulbs not included). (Don't exceed the maximum capacity that recommended on the sockets).

OUTLET BOX WHITE WIRE BLACK WIRE WIRE CONNECTOR WIRE CONNECTOR GROUND WIRE MOUNTING BAR MOUNTING SCREW GROUND SCREW-WASHER HEX NUT NIPPLE -CANOPY TOP LOOP -TOP NUT QUICK LINK WIRE. CHAIN QUICK LINK LOOP QUICK LINK HOOK LONG HUNG ROD SOCKET QUICK LINK HOOK SHORT HUNG ROD

INSTALLATION IS NOW COMPLETED.