

# IN21141PN

## INSTALLATION INSTRUCTIONS

Please read carefully and save these instructions as you may need them a later date.

### CAUTION

Turn off the main power at the circuit breaker before installing the fixture, in order to prevent possible shock.

### GENERAL

All electrical connections must be in accordance with local and National Electrical Code (N.E.C) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustration.

## ASSEMBLY AND INSTALLATION

1. Place the socket sleeves onto the sockets.
2. Thread tube-1 onto the coupling, then attach the shade on Tube-1. Thread Tube-2 onto Tube-1 and tighten the shade.
3. Put the fixture wire through the rods (Adjust the desired height with the different rods and canopy assembly. Secure rods to Tube-2.)
4. Thread the support screws to the Cross bar and secure with the hex nut.
5. Secure the cross bar to the outlet box with the mounting screws.
6. Pull out the outlet wire and ground wire from the Outlet Box.  
Make wire connections:  
---White wire from light to White Wire from power source.  
---Black wire from light to Black Wire from power source.  
---Attach the Ground Wire to cross bar with a Green Screw.
7. Align the canopy assembly against the Outlet box, secure with the ball nuts.
8. Install bulbs:(bulbs not included)  
(Don't exceed the maximum capacity recommended on the Sockets).

INSTALLATION IS NOW COMPLETED.

1500 Cherokee Parkway, Suite 100, Acworth, GA 30102  
Phone: (866) 845-5451 • Fax: (866) 816-6165  
E: [service@acclaim-lighting.com](mailto:service@acclaim-lighting.com) • [www.acclaim-lighting.com](http://www.acclaim-lighting.com)

**ACCLAIM**  
**LIGHTING**  
INTERIOR • OUTDOOR

