

1500 Cherokee Parkway, Suite 100, Acworth, GA 30102

Phone: (866) 845-5451 • Fax: (866) 816-6165

E: service@acclaim-lighting.com • www.acclaim-lighting.com

## IN21200 INSTALLATION INSTRUCTIONS

Please read carefully and save these instructions, as you may need them at a later date.

## **CAUTION**

WARNING: Risk of Fire. Consult a qualified electrician to ensure correct branch circuit conductor. Min 90°C supply conductors.

Turn off the main power at the circuit breaker before installing the fixture, in order to prevent possible shock.

## **GENERAL**

All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustrations on the installation instructions.

## ASSEMBLY AND INSTALLATION

- 1. Connect stems (13)(14)(15) one by one, then attach them to lamp body (16) and thread the stem (13) into canopy (11).
- 2. Thread two mounting screws (5) to the mounting bar (7) and secure with the hex nut (9).
- 3. Secure the mounting bar (7) with box screws (10) to the outlet box (1).
- 4. Pull out the outlet wire and ground wire from the outlet box (1). Make wire connections
- --Ribbed wire (w/o marking) from light to White wire (2) from power source.
- --Smooth wire (w/o marking) from light to Black wire (3) from power source.
- --Loop the ground wire (4) to mounting bar (7) with a ground screw (8).
- 5. Attach the canopy (11) against the outlet box (1), secure with the ball nut (12).
- 6. Put glass shade (17) around socket inside lamp body (16), and secure with socket ring (18).

INSTALLATION IS NOW COMPLETED

