CRYST RAMA



ASSEMBLY INSTRUCTION MODEL #GAB-B7312-MK



DETAILED ILLUSTRATION



- E= -**@e@e@@e@**@@e@@@@@

Crystal Key

- A.3 Sets.
- (15)14mm + (17)20mm + (4)30mm B.3 Sets.
- (13)14mm + (16)20mm + (4)30mm
- C.3 Sets. (20)14mm + (13)20mm + (3)30mm D.4 Sets.
- (8)14mm + (8)20mm + (2)30mm E.4 Sets.
- (5)14mm + (8)20mm + (3)30mm F.4 Sets.
- (12)14mm + (6)20mm + (2)30mm G.6 Sets.
- (3)14mm + (3)20mm + (1)30mm H.6 Sets. (4)14mm + (2)20mm + (1)30mm
- (4)14/min + (2)20/min + (1)50/mi I.6 Sets.
- (2)14mm + (5)20mm + (1)30mm
 - H= • ⊛ ⊛ ⊛ ⊛ ⊛ ⊛

 - M=-
 - N= -

 - P= -
 - 0=-

J.6 Sets. (4)14mm + (2)20mm + (1)30mm K.6 Sets. (4)14mm + (2)20mm L.6 Sets. (2)14mm + (3)20mm + (1)30mm M.8 Sets. (2)14mm + (1)20mm + (1)30mm N.8 Sets. (2)14mm + (2)20mm + (1)30mm 0.8 Sets. (2)14mm + (2)20mm P.8 Sets. (1)14mm + (3)20mm + (1)30mm Q.8 Sets. (1)14mm + (2)20mm + (1)30mm R.8 Sets. (4)14mm + (2)20mm S.8 Sets. (2)14mm + (2)20mm + (1)30mm

WARNING: This product can expose you to Lead, which is known to the State of California to cause cancer and/or birth defects or reproductive harm. For more information go to www.P65Warnings.ca.gov.

CRYST RAMA LIGHTING THE WAY FOR SIXTY YEARS



PART NUMBER MODEL #GAB-B7312-MK



Part Number

- A.(1) Mounting Hardware
- B.(1) Canopy(W5.12",H0.79") #XRE7312MKCAN5.12IN
- C.(1) Collar Ring
- D.(1) Collar Loop
- E.(2) Quick Link
- F. (1) Hanging Chain(72",4mm) #XRE7304MKCHA4MM
- G.(1) Fixture Loop
- H.(1) Ball Nut #XRE7306MKBANUT I.(1) Check ring(D20xH5mm)
- J.(1) Cover(D132xH5mm)

- M.(12) Candle Sleeve(W0.87",H3.94") #XRE7312MKCDL3.94IN N.(4) Upper Arms







ASSEMBLY INSTRUCTION MODEL #GAB-B7312-MK



Please place the frame on a soft cloth covered table before installation.

Please do not remove the bubble wrap on the frame until the installation is completed..

- 1. Loosen the cover by removing the loop, check ring and hex nut. Loosen the hex nut on the top of the arms using a wrench and spread the arms out equally.
- 2. Feed the lead wire from bottom ring through the end of one arm(the end with coupler) and exit out of the distributor box.
- 3. Insert the coupler, at the bottom end of the lower arm, onto the stud on the bottom ring and secure it by inserting a screw and tightening it with the included "L" wrench. Repeat for the other lower arms.
- 4. Secure the other end of the arms onto the distributor box by tightening up the hex nut.
- 5. Connect the wire to the wire terminal .
- 6. Tuck the wires carefully inside the distributor box and put the cover back and secure with hex nut. Place the check ring over the hex nut and secure with loop.
- 7. Dress the crystal as illustrated.
- 8. Slide the candle sleeve over the socket and install the bulb(not included).