

MICA INSTALLATION INSTRUCTIONS FOR #21177

Shade

Tabs

(Mica panel)

Outer rim

IMPORTANT

TURN OFF THE POWER AT THE MAIN FUSE OR
CIRCUIT BREAKER BOX BEFORE STARTING
INSTALLATION

CAREFULLY UNPACK AND IDENTIFY ALL
PARTS BEFORE ASSEMBLY. BULBS ARE NOT
INCLUDED

- 1.) Lift slightly the tabs that hold or would hold the mica in place.
- 2.) Place mica into shade as seen here. Do not over bend. The curve (bend) should be similar to what you see here.
- 3.) Bend the center and two side tabs, followed by the four outer rim tabs.
- 4.) Enjoy your new and improved shade!



"A Commitment to Excellence in Lighting and Service"

CALL OUR CUSTOMER SERVICE DEPARTMENT AT 1-800-222-4009

MONDAY - FRIDAY 8:00a.m - 6:00p.m ET

visit us on the web at www.meyda.com