



ASSEMBLY INSTRUCTIONS

1. Carefully unpack and identify all parts referring to illustration for parts identification.
2. Turn the power to the installation point OFF.
3. Screw the center rod(10) onto the fixture body(6), then install the rattan column(9) onto the fixture body(6) using the knurled nut(8).
4. While threading wire through, assemble the rods(5) together using the nipples(4), then attach the bottom end of the rod(5) onto the center rod(10) until tight.
5. Secure the loop(3) onto the top rod(5).
6. Use the quick link to connect the loop(3) to the loop on the canopy(1) and twist the locking mechanism to secure.
7. Install proper bulbs(not included) into socket referring to the markings and/or labels on the fixture for maximum wattage.
8. Screw the glass(7) onto the fixture body(6). Make sure glass is secure before releasing.
9. Refer to the additional installation instructions included with the product for wiring and installation.
10. Restore power to the installation point and retain this sheet for future reference.