



ASSEMBLY INSTRUCTIONS

1. Carefully unpack and identify all parts referring to illustration for parts identification.
2. Turn the power to the installation point OFF.
3. Assemble the rods (5) together using the nipple (4). Attach the bottom end of rods (5) onto the coupling (7). Attach the other end of rods (5) onto the loop (6).
4. Install the glass shade (2) onto the cover (3).
5. Refer to the additional installation instructions included with the product for wiring and installation.
6. Restore power to the installation point and retain this sheet for future reference.