

# UTTERMOST

## ASSEMBLY INSTRUCTIONS

**STYLE#: 21540**

**WARNING:** TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER BEFORE INSTALLING OR SERVICING THIS FIXTURE.

*Carefully unpack all lamp parts from carton. We suggest a licensed electrician for all fixture installations.*

1. Take the lamp carefully out of the Carton, and place on a flat surface.
2. Be sure power to the installation point is OFF. Follow the steps below for assembly.
3. Adjust the length of wire needed for your installation, remove excess. Determine the number of **Rods** to be assembled to the **Fixture Body** as needed for your hanging height. Pull the Supply Wire with Ground Wire through the selected **Rods** and **Swivel**. Thread the **Rods** & connect **Nipple**. Hand tighten.
4. Pass the supply wire through the **Universal Bar** assembly, secure the **Universal Bar** to the Outlet Box with Outlet Box Screws.
5. Fasten the **Universal Bar** to the **Canopy**. Thread **Mounting Screws** to secure it. Tighten until snug with screwdrivers.
6. Connect the wire as shown. (See Figure 1)
  - a. Connect the House Ground Wire to the Fixture Ground Wire, secure with wire nut.
  - b. Connect the House White (or Ribbed) Wire to the Fixture Supply Wire (White or Ribbed Side), secure with wire nut.
  - c. Connect the House Black (or Red) Wire to the Fixture Supply Wire (Black or Smooth Side), secure with wire nut.
  - d. Carefully stuff all of the connected wires into the Outlet Box.

7. Place **Glass Shade** instruction as below. (See Figure 2)

Step 1: Place the **Socket** to about 45 degree. Install correct **Bulbs** referring to fixture markings and/or labels for maximum wattage. (T30 Bulbs Included)

Step 2: Lift **Metal Cap** up through the **Socket** to allow enough space when placing **Glass Shade** into the **Socket**.

Step 3: Carefully turn back the **Socket** together with the **Glass Shade** back to Straight. And sit the **Glass Shade** onto the **Metal Ring**. Put the **Metal Cap** put down to cover the Glass top.

Step 4: Then remove the "U" **Plastic Protector** of the **Metal Cap**.

**Your installation is completed now. Restore electricity.**

Figure 1

