

Assembly Instruction

| Hardw | are list | | STYLE:24701 |
|------------|------------------|-----|-------------|
| / | WRENCH Ø6 | (1) | 1PCS |
| 0 | FLAT WASHERS & 6 | (2) | 6 PCS |
| (2) | FLAT WASHERS Ø6 | (3) | 3 PCS |
| G**** | SCREW Ø6x45 | (4) | 3 PCS |
| / | WRENCH Ø 8 | (5) | 1PCS |
| (grance) | SCREW Ø 8x25 | (6) | 10PCS |
| 0 | FLAT WASHERS Ø8 | (7) | 11PCS |
| (British | SCREW Ø 8x50 | (8) | 1PCS |

1. Take the parts carefully out of the carton. and than place them on a flat and soft surface, making sure that the parts will not be damaged.

2. Place the main part on a flat and soft surface, put the backrest and armrest tube into the holes on the top of the seat. Then screw the backrest into the screw hole on the armrest and use the wrench to secure tightly.

3. Turn the seat over and connect the 2pcs legs into the backrest/armrest tube at the bottom of the seat, then screw the legs into the screw holes under the bottom of the seat and use the wrench to secure tightly.

4. The assembly is completed.

To clean, wipe with soft dry cloth.

| Part | s list | | |
|------|-----------|-----|------|
| Α | LEGS | | 2PCS |
| В | MAIN PART | 8 4 | 1PCS |
| С | BACKREST | | 1PCS |
| D | ARMREST | | 1PCS |







