


# ASSEMBLY INSTRUCTIONS

ITEM NO : BO-216

1. CAREFULLY UNPACK AND PLACE ALL PARTS ON A SMOOTH SURFACE AND LAY THEM UP AS PER THE SKETCH.
2. SCREW TUBE ( B ) ONTO BASE ( A ),PART ( C ) ONTO TUBE ( B ),PART ( D ) ONTO PART ( C ).
3. INSERT THE HARP ( E ) INTO THE CUP OF PART ( D ).
4. PLACE THE SHADE ( NOT INCLUDED ) ON THE HARP ( E ) AND SCREW THE FINIAL ( F ) TIGHTLY,THEN ADJUST THE SHADE HORIZONTAL.
5. UNSCREW THE NUT ( G ),AND ADJUST THE ARM ( H ) TO APPROPRIATE HEIGHT,THEN SCREW THE NUT ( G ) TIGHTLY.
6. IF NECESSARY ADJUST THE COLUMNS AND TIGHTEN THE SCREWS ( I ) USING THE HEX-DRIVER PACKED WITH THE MANUAL. FOR FURTHER USE, DO NOT THROW AWAY THE TINY DRIVER.
7. INSERT THE POLARIZED PLUG INTO OUTLET, TURN ON THE SWITCH AND ENJOY YOUR LAMP.



**WATTAGE : 150W 3 WAY TYPE A ( BULB NOT INCLUDED )**

## IMPORTANT SAFETY INSTRUCTIONS :

THIS PORTABLE LAMP HAS A POLARIZED PLUG ( ONE BLADE IS WIDER THAN THE OTHER AS A FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT,CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.

**SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE**