


ASSEMBLY INSTRUCTIONS

ITEM NO:BO-2944FL-DB

CAREFULLY UNPACK AND PLACE ALL PARTS ON A SMOOTH SURFACE.

- 1.SCREW POLE (D) CLOCKWISE INTO POLE (C) TO TIGHTTEN.
- 2.SCREW POLE (E) CLOCKWISE INTO POLE (D) TO TIGHTTEN.
- 3.SCREW POLE (E) CLOCKWISE ONTO BASE (F) TO TIGHTEN.
PULL EXTRA CORD OUT FROM BASE .
- 4.INSTALL 60W EDISON BULB (INCLUDED) INTO THE SOCKET .
- 5.INSERT THE POWER PLUG INTO AN OUTLET AND ENJOY !!



Use MAX 60 Wattage edison bulb(included) or type A bulb (bulb not included)

IMPORTANT SAFETY INSTRUCTIONS:

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.