

ASSEMBLY INSTRUCTIONS


ITEM NO.: BO-2963-3

Carefully place all parts on smooth surface to assembly.

1. TIGHTEN THE SOCKET (B) ONTO THE BASE (A) ;
2. INSERT HARP (E) TO THE BRACKET OF THE SOCKET (C);
3. PUT SHADE (F) ON HARP (E) AND TIGHTEN BY FINIAL (G);
4. INSTALL RECOMMENDED BULB ONTO THE LAMPHOLDER (D)
(NOT INCLUDED IN THIS PACKING).

INSERT PLUG INTO AN OUTLET
AND ENJOY YOUR LAMP!!


**Use Max 100W type A bulb
(bulb not included)**



1. SCREW POLE (B) TO BASE (A) AND POLE (C) TO POLE (B),
POLE (D) TO POLE (C), PULL ADDITIONAL WIRE FROM THE
SIDE, OF THE BASE;
2. INSERT HARP (G) TO THE BRACKET OF THE SOCKET (E);
3. PUT SHADE (H) ON HARP (G) AND TIGHTEN BY FINIAL (I);
4. INSTALL RECOMMENDED BULB ONTO THE LAMPHOLDER (F).
(NOT INCLUDED IN THIS PACKING).

INSERT PLUG INTO AN OUTLET
AND ENJOY YOUR LAMP!!

**Use Max 100W type A bulb
(bulb not included)**



THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY AND EASILY INSERTED. DO NOT ATTEMPT TO ALTER THE PLUG.

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.