


# ASSEMBLY INSTRUCTIONS

## BO-3058DK-BS

CAREFULLY PLACE ALL PARTS ON A SMOOTH SURFACE AND LAY THEM UP PER THE SKETCH BELOW.

1. INSTALL RECOMMENDED BULB (B), BULB NOT INCLUDED IN THIS PACKAGE.
2. PUT SHADE (C) ONTO THREAD PIPE (M).
3. PUT TOP DIFFUSER(D) AND WASHER (E) ONTO THREAD PIPE(M) , TIGHTEN WITH FINIAL(F).
4. PUT RUBBER WASHER (G), METAL WASH (H), BOTTOM DIFFUSER ((I) AND WASHER (J) ONTO THREAD PIPE (N) AND TITHTEN WITH FINIAL (K).
5. INSERT THE PLUG INTO AN OUTLET.

ENJOY YOUR LAMP!!



**Use Max 2X40W type A  
bulb (bulbs not included)**

**\*\*\* 1 USB PORT AND 1 TYPE-C  
CHARGING PORT AND 1 OUTLET  
PORT PROVIDED! \*\*\***

*\* TO REDUCE THE RISK OF ELECTRIC SHOCK, ALWAYS UNPLUG FROM THE ELECTRICAL OUTLET BEFORE INSTALLATION.*

*\* THIS FIXTURE IS SUITABLE FOR DRY LOCATION ONLY.*

*\* THIS FIXTURE SHOULD ONLY BE CLEANED WITH A SOFT LINT FREE CLOTH DAMPLED WITH WATER. DO NOT USE ANY CHEMICAL OR ABUSIVE CLEANER AS THEY MAY DAMAGE THE SURFACE OF THE PRODUCTS.*

**SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.**