

ASSEMBLY INSTRUCTIONS

ITEM NO: BO-3133TB-AB / BO-3133TB-BS / BO-3133TB-GR

TAKE THE LIGHTING FIXTURE FROM THE PACKAGING AND LAY IT ON A SMOOTH SURFACE.

*** NEED NOT TO MAKE ANY ASSEMBLY.


*** THIS FIXTURE IS EQUIPPED WITH A WIRELESS CHARGING PAD.

JUST INSERT THE PLUG (H) INTO AN OUTLET.

ENJOY YOUR LAMP!!

*** This LED light provides low maintenance service with no bulbs to change.***

**Use Max 12W LED
bulb (bulbs Included)**



** TO REDUCE THE RISK OF ELECTRIC SHOCK, ALWAYS UNPLUG FROM THE ELECTRICAL OUTLET BEFORE INSTALLATION.*

** THIS FIXTURE IS SUITABLE FOR DRY LOCATION ONLY.*

** THIS FIXTURE SHOULD ONLY BE CLEANED WITH A SOFT LINT FREE CLOTH DAMPLED WITH WATER. DO NOT USE ANY CHEMICAL OR ABUSIVE CLEANER AS THEY MAY DAMAGE THE SURFACE OF THE PRODUCTS.*

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY AND EASILY INSERTED. DO NOT ATTEMPT TO ALTER THE PLUG.

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.