ASSEMBLY INSTRUCTIONS


ITEM NO:BO-3165TB

CAREFULLY UNPACK AND PLACE ALL PARTS ON A SMOOTH SURFACE.

- 1. SCREW THE POLE (B) ONTO THE BASE (A) TO TIGHTEN.
- 2. SCREW THE ASSEMBLE SOCKET (C) INTO THE POLE (B) TO TIGHTEN.
 GET THE REMAINING SLACK OF THE POWER CORD OUT FROM BASE HOLD.
- 3. PUT THE FELT PAD (D) TO THE BOTTOM OF THE BASE (A).
- 4. SCREW THE THREADED ROD (E) INTO ASSEMBLE SOCKET (C) TO TIGHTEN.
- 5. PUT WASHER (F) INTO THE THREADED ROD (E).

6. PUT THE SHADE (G) OVER THREADED ROD (E), THEN TIGHTEN FINIAL (H) SECURING THE SHADE IN PLACE.

- 7. INSTALL BULB (NOT INCLUDED) INTO THE SOCKET.
- 8. INSERT THE POWER PLUG INTO AN OUTLET AND ENJOY!!



— Н

Use MAX 2 x 60 Wattage Type A bulb (bulb not included)

IMPORTANT SAFETY INSTRUCTIONS:

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.