

# ASSEMBLY INSTRUCTIONS


**ITEM NO: LA-8032DK-1 LA-8032DK-2**

1. TAKE THE LIGHTING BODY OUT FROM THE PACKAGING.  
NO NEED TO ASSEMBLE ANY PARTS OR BULBS.


2. INSERT THE PLUG (A) INTO AN OUTLET AND TURN ON THE DIMMER SWITCH (B).

**\*\*\* 2 USB CHARGING PORTS IS ALSO PROVIDED! \*\*\***

ENJOY YOUR LAMP!!



**LA-8032DK-2 :**  
**Use Max 15WX2 LED bulbs**  
**(bulbs included)**



**LA-8032DK-1 :**  
**Use Max 15W LED bulbs**  
**(bulbs included)**

**\*\*\* THIS LED LIGHT PROVIDES LOW MAINTENANCE SERVICE WITH NO BULBS TO CHANGE.\*\*\***

*\* TO REDUCE THE RISK OF ELECTRIC SHOCK, ALWAYS UNPLUG FROM THE ELECTRICAL OUTLET BEFORE INSTALLATION.*

*\* THIS FIXTURE IS SUITABLE FOR DRY LOCATION ONLY.*

*\* THIS FIXTURE SHOULD ONLY BE CLEANED WITH A SOFT LINT FREE CLOTH DAMPLED WITH WATER. DO NOT USE ANY CHEMICAL OR ABUSIVE CLEANER AS THEY MAY DAMAGE THE SURFACE OF THE PRODUCTS.*

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY AND EASILY INSERTED. DO NOT ATTEMPT TO ALTER THE PLUG.

**SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.**