

T25/16 PLUG-IN TIMER

INSTRUCTIONS

1. Locate an electrical outlet near the device to be operated.

2. TO SET THE CLOCK TIMER:

A. Hold the timer so the white face is toward you, and the manual switch is on top.

B. Turn the outer rim of the timer face (the section with numbers) clockwise until the arrow on the inner rim points to the approximate time of day.

NOTE: The numbers on the timer face correspond to the hours in a day. Each hour is divided into four fifteen minute sections.

3. TO SET TIME ON :

A. Locate push pegs on the outer rim of the timer face.

B. Using thumb or fingernail, firmly push pegs outward from the timer face until you hear an audible click . **NOTE:** Each peg keeps light or appliance "ON" for fifteen minutes. Use as few or as many pegs as necessary throughout the day.

4. Time OFF is automatically set by leaving the tan pegs flush against the timer face.

Note: You can set multiple on or off programs.

5. Locate override switch on top of timer. Make sure it is set to AUTO .

6. Plug the light or appliance to be controlled into the timer.

7. Plug the timer into the outlet.

8. TO OVERRIDE THE TIMER:

A. Locate the override switch on top of the timer.

B. Push switch to the ON position. Use the light or appliance as you normally would.

NOTE: To reactivate timer, slide switch back to AUTO .