

10" Shades

→ P10-111

FINISH: Polished Brass
 HEIGHT: Adjusts from 0" to 14"
 BASE: 5 3/4" Octagon
 BULB: One 40T10 or 60T10
 SWITCH: On shade
 SHADE: 10"
 CORD: 9' Brown



← P10-111-71

FINISH: Antique Brass
 HEIGHT: Adjusts from 0" to 14"
 BASE: 5 3/4" Octagon
 BULB: One 40T10 or 60T10
 SWITCH: On shade
 SHADE: 10"
 CORD: 9' Brown



↑ P10-111-MB

FINISH: Mahogany Bronze
 HEIGHT: Adjusts from 0" to 14"
 BASE: 5 3/4" Octagon
 BULB: One 40T10 or 60T10
 SWITCH: On shade
 SHADE: 10"
 CORD: 9' Brown



← P10-160-617

FINISH: Black with Polished Brass Accents
 HEIGHT: Adjusts from 0" to 10"
 BASE: 6" round
 BULB: One 40T10 or 60T10
 SWITCH: On shade
 SHADE: 10"
 CORD: 9' Black



← P10-165-627

FINISH: Chrome w/ Black
 HEIGHT: Adjusts from 7" to 16.5"
 BASE: 6" round
 BULB: One 40T10 or 60T10
 SWITCH: On shade
 SHADE: 10"
 CORD: 9' Black

