

## DESK/PIANO LAMPS



### ← P14-202-81

FINISH: Mahogany Bronze  
 HEIGHT: Adjusts from 0" to 13"  
 BASE: 5" Square  
 BULB: Two 40T10 or 60T10  
 SWITCH: On base  
 SHADE: 14"  
 CORD: 9' Brown



### → P14-202-AB

FINISH: Antique Brass  
 HEIGHT: Adjusts from 0" to 13"  
 BASE: 5" Square  
 BULB: Two 40T10 or 60T10  
 SWITCH: On base  
 SHADE: 14"  
 CORD: 9' Brown



### ↑ P14-202-GT

FINISH: Granite  
 HEIGHT: Adjusts from 0" to 13"  
 BASE: 5" Square  
 BULB: Two 40T10 or 60T10  
 SWITCH: On base  
 SHADE: 14"  
 CORD: 9' Brown



### → P14-202

FINISH: Polished Brass  
 HEIGHT: Adjusts from 0" to 13"  
 BASE: 5" Square  
 BULB: Two 40T10 or 60T10  
 SWITCH: On base  
 SHADE: 14"  
 CORD: 9' Brown