

14" Shades



↑ **P14-231-61**
FINISH: Polished Brass
HEIGHT: Adjusts from 0" to 12"
BASE: 6" round
BULB: Two 40T10 or 60T10
SWITCH: In-line 6" from base
SHADE: 14"
CORD: 9' Brown



← **P14-231-71**
FINISH: Antique Brass
HEIGHT: Adjusts from 0" to 12"
BASE: 6" round
BULB: Two 40T10 or 60T10
SWITCH: In-line 6" from base
SHADE: 14"
CORD: 9' Brown



← **P14-212**
FINISH: Polished Brass
HEIGHT: Adjusts from 0" to 16"
BASE: 6 3/8" Decagon
BULB: Two 40T10 or 60T10
SWITCH: On base
SHADE: 14"
CORD: 9' Brown



→ **P14-212-WB**
FINISH: Weathered Brass
HEIGHT: Adjusts from 0" to 16"
BASE: 6 3/8" Decagon
BULB: Two 40T10 or 60T10
SWITCH: On base
SHADE: 14"
CORD: 9' Brown