

# Upright Piano Lamps



## ← P14-250

FINISH: Polished Brass  
 HEIGHT: Adjusts from 0" to 8"  
 BASE: 6" round  
 BULB: Two 40T10 or 60T10  
 SWITCH: In-line 6" from base  
 SHADE: 14"  
 CORD: 9' Brown

**PF14-201**  
 FLUORESCENT OPTION  
 Uses One T5 Fluorescent Bulb



## ↑ P10-150

FINISH: Polished Brass  
 HEIGHT: Adjusts from 0" to 8"  
 BASE: 6" round  
 BULB: One 40T10 or 60T10  
 SWITCH: On shade  
 SHADE: 10"  
 CORD: 9' Brown



## ↑ P14-250-617

FINISH: Black with Polished Brass Accents  
 HEIGHT: Adjusts from 0" to 8"  
 BASE: 6" round  
 BULB: Two 40T10 or 60T10  
 SWITCH: In-line 6" from base  
 SHADE: 14"  
 CORD: 9' Black

## → P10-150-617

FINISH: Black with Polished Brass Accents  
 HEIGHT: Adjusts from 0" to 8"  
 BASE: 6" round  
 BULB: One 40T10 or 60T10  
 SWITCH: On shade  
 SHADE: 10"  
 CORD: 9' Black

