Erlenmeyer Floor Lamp 247810 & 247810C

To Install Bulb & Glass (Figure 1)

Component Parts

- A Fixture
- B Pin
- C Glass
- D Thumbscrews (4)
- 1. Carefully unpack the lamp from the carton.
- 2. Install bulb into socket. *Bulb is included* with the "C" version only.
- 3. Loosen thumbscrews (D) . It is not necessary to remove thumbscrews.
- Slip glass (C) into ring aligning groove in glass with thumbscrews (D) and tighten thumbscrews (D). Do not overtighten.
- Glass maybe be rotated to a variety of angles. While holding glass, remove pin (B) and orient glass into desired position. Replace pin (B) thru tab and engage with gear.




Figure 1

If you need further assistance, or find that you are missing any parts, please contact the dealer from which you purchased this product. We hope you enjoy your fixture!

* Hubbardton Forge will not be liable for injury or damage caused by improper installation, lamping or use of this fixture.



Hand-Forged, Vermont-Made Lighting and Accessories 154 Route 30 South, Castleton, Vermont 05735