

SARELLA RS8315N- ___ H





THIS DESIGN IS THE PROPRIETARY TRADE DRESS/TRADEMARK OF W SCHONBEK LLC.


Diameter: 41" Height: 35"


Hanging Weight: 41lbs.

















19 Connect arm wires using plug-in connectors on top and bottom tiers. See detailed illustration.



- **20** Push wires into hole and attach arm into place by tightening screws.
- **21** Install bobeche on every arm and screw bulbs into all sockets and test fixture before trimming. If any of the bulbs do NOT light DISCONNECT POWER. Double check the wire connections.
- **22** Install scroll(s) into hole pattern in top washer. Tighten screw to secure scroll(s) in place.






SARELLA RS8315N- ___R





THIS DESIGN IS THE PROPRIETARY TRADE DRESS/TRADEMARK OF W SCHONBEK LLC.


10 + 5 Lights
Diameter: 41"
Height: 35"
Hanging Weight: 41lbs.
















19 Connect arm wires using plug-in connectors on top and bottom tiers. See detailed illustration.



- **20** Push wires into hole and attach arm into place by tightening screws.
- **21** Install bobeche on every arm and screw bulbs into all sockets and test fixture before trimming. If any of the bulbs do NOT light DISCONNECT POWER. Double check the wire connections.
- 22 Install scroll(s) into hole pattern in top washer. Tighten screw to secure scroll(s) in place.





SARELLA RS8315N- ___S





THIS DESIGN IS THE PROPRIETARY TRADE DRESS/TRADEMARK OF W SCHONBEK LLC.


Diameter: 41" Height: 35"


Hanging Weight: 41lbs.














19 Connect arm wires using plug-in connectors on top and bottom tiers. See detailed illustration.



- **20** Push wires into hole and attach arm into place by tightening screws.
- **21** Install bobeche on every arm and screw bulbs into all sockets and test fixture before trimming. If any of the bulbs do NOT light DISCONNECT POWER. Double check the wire connections.
- 22 Install scroll(s) into hole pattern in top washer. Tighten screw to secure scroll(s) in place.

