
ASSEMBLY INSTRUCTIONS



Marine Outdoor Wall Light Item # SLO2001


WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN.

WARNING *** SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION. INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL. ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

- Attach ground (green) wire to ground wire from wall outlet box (usually green or copper in color), fasten together with a plastic wire connector. Tightly wrap the wire connector with electrical tape so the end of the connector is sealed. IT IS IMPERATIVE THAT THE OUTLET BOX IN YOUR HOME BE PROPERLY GROUNDED.
- Connect neutral (white) fixture wire coming from future base to neutral (usuall white) outlet wire. Fasten both wires together with a plastic wire connector and tightly wrap the wire connector with electrical tape.
- Follow the same procedure to connect the hot future wire (black) to the hole wire (usually black) from wall outlet box. Always make sure that no wire strands are left outside of the connectors. DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.
- 4. Remove mounting strap (A) from fixture base (C) by loosening set screw (D)
- Attach mounting strap (A) to wall outlet box and secure by inserting mounting screws (B) into screw holes at wall outlet box. Neatly tuck wires into wall outlet box, attach future base (C) to mounting strap (A), and secure with set screw (D). Insert light bulb into socket.
- 6. Carefully insert glass shade (F) into glass holder (G), and attach washer (H) and glass holder (G) to bottom threaded opening of part (E).



ASSEMBLY INSTRUCTIONS



Marine Outdoor Wall Light

Item # SLO2001

WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN.

WARNING *** SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION.

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

INSTRUCTIONS FOR MOUNTING FIXTURE OUTDOORS AND/OR IN WET

- Mounting surface should be clean, dry, flat and 1/4" larger than the backplat on all sides. Any gaps between the mounting surface and backplate exceeding 3/16" should be corrected as required.
- With silicone (ex. GE-108) caulking compound, caulk completely around where back of the backplate meets the wall surface to prevent water from seeping into outlet box.

