







50136 , STORM CEILING LAMP

PARTS LIST/Liste des pièces			
A			x1
B		Starter bulb included	x1
C	C.1 	P3	x3
	C.2 	Ø7x30mm	x3
	C.3 	Ø4x30mm	x3



Assembly Instructions:

1. Before assembling, turn the power switch off or unplug the lamp.
2. Use one (1) G4, LED Max 3W 3000K.
3. To avoid scratches and damages, use proper tools to assemble the lamp.
4. For safety, keep children away from the electric parts of the lamp.

If the external wire or cable is damaged, only the manufacturer, service agent or qualified electrician can do the repairing to avoid danger.

Instructions d'Assemblage:

1. Avant l'assemblage, couper la source d'alimentation du courant électrique.
2. Utiliser une ampoule (1) G4, LED Max 3W 3000K.
3. Pour éviter de faire des égratignures et dommages, ne pas se servir d'outils durs ou pointus pour l'assemblage de cette lampe.
4. Pour leur protection, tenir les enfants loin des conduits électriques.

Si un fil ou câble extérieur se brise, faire réparer seulement par le fabricant, son agent ou une personne qualifiée afin d'éviter tout danger.

For missing parts or damaged parts, please call : USA : 1-866-798-6663 Canada : (514) 382-6661