

# IN41030 INSTALLATION INSTRUCTIONS

1500 Cherokee Parkway, Suite 100, Acworth, GA 30102  
Phone: (866) 845-5451. Fax: (866) 816-6165  
www.acclaim-lighting.com

**ACCLAIM**  
LIGHTING  
INTERIOR • OUTDOOR

Please read carefully and save these instructions as you may need them a later date.

## CAUTION

Turn off the main power at the circuit breaker before installing the fixture in order to prevent possible shock.

## GENERAL

All electrical connections must be in accordance with local and National Electrical Code (N.E.C) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustration.

## ASSEMBLY AND INSTALLATION

1. Screw 2-12" rods together and thread them to the bottom of the back plate.
2. Attach the 2 support screws to the CROSS BAR with hex nuts.
3. Drill two holes in the wall, then insert two anchors into the holes.
4. Attach the cross bar to the wall using the 2 mounting screws.
5. Thread the two support screws through the back plate and secure with two ball nuts.
6. Install the bulb into the socket (Bulb not included).  
(Do not exceed the maximum capacity recommended on the Sockets)
7. Move the swing arms at the angle you want (the angles within 180 degrees).
8. Insert the Plug in the outlet, then turn on the main power at the circuit breaker.

INSTALLATION IS NOW COMPLETED.

