



US ELECTRICITY


CROSS / LINEAR
DETAILS KIT

INSTRUCTION MANUAL US
MANUEL D'UTILISATION É.-U.
MANUAL DE INSTRUCCIONES (EE. UU.)






US.BUSTERANDPUNCH.COM L0260 For wiring and plate installation, refer to module instruction manual.



NOTE:

For removal, follow steps in reverse.



To allow for easier assembly, insert a $3/16^{\circ} - 7/32^{\circ}$ (5 – 5.5mm) flat head screwdriver and rotate 360° to remove excess material from the flat section of the insert.

There will be some resistance (a little more than turning a key in a lock) and a small amount of material may come loose – this is normal.

Ensure screwdriver is held straight to avoid misalignment and off-center rotation when installed.

CROSS DETAILS:

