

ASSEMBLY INSTRUCTIONS


ITEM NO.: BO-2960TB-2

Carefully place all parts on smooth surface to assembly.

1. TIGHTEN THE SOCKET (B) ONTO THE BASE (A) ;
2. INSERT HARP (D) TO THE BRACKET OF THE SOCKET (C);
3. PUT SHADE (E) ON HARP (D) AND TIGHTEN BY FINIAL (F);
4. INSTALL RECOMMENDED BULB (NOT INCLUDED IN THIS PACKING).

INSERT PLUG INTO AN OUTLET AND ENJOY YOUR LAMP!!

**Use Max 100W type A bulb
(bulb not included)**



THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY AND EASILY INSERTED. DO NOT ATTEMPT TO ALTER THE PLUG.

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.