

ASSEMBLY INSTRUCTIONS

ITEM NO: BO-3154TB

1. Place the **Lamp Base** in an upright position on the floor, be sure the power to the installation point is power off.

2. Locate the **Harp** by pressing the bottom ends of the **Harp** into the **Saddle**.


3. Place the center hole on the top of the Shade over the nipple at the top end of the **Harp**. Secure the Shade by threading the **Finial** onto the **Harp**.

Hand tighten until snug.

4. Install correct **Bulb** referring to fixture markings and /or labels for maximum wattage. USE 150W

(MAXIMUM) 3-WAY TYPE A

BULB (BULB NOT INCLUDED)



IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to defeat this safety feature.

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.