

ASSEMBLY INSTRUCTIONS:

ITEM NO: BO-547

1. CAREFULLY UNPACK AND PLACE ALL PARTS ON A SMOOTH SURFACE AND LAY THEM UP AS PER THE SKETCH.
2. INSERT HARP (B) INTO SADDLE (A).
3. PUT SHADE (NOT INCLUDE) ONTO HARP (B) THEN SCREW FINIAL (C) TO TIGHTEN THE SHADE.

THE SPECIFICATION OF THE MATCHING SHADE SHOULD BE:

1. Minimum opening area is 16 inch².
2. Minimum lamp-to-shade spacing is 4-3/4".
3. Minimum height is 9".

CAUTION: Use 3-way 150W type A or smaller bulb .

IMPORTANT SAFETY INSTRUCTIONS:

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.

***SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.**

