


ASSEMBLY INSTRUCTIONS

ITEM NO: LA-8032FL

1. TAKE THE LIGHTING BODY OUT FROM THE PACKAGING.
2. INSERT BODY PART (A) TO THE POLE (B) AND TIGHTEN WITH TWO SIDE SCREWS (F).
3. INSERT POLE (B) TO BASE (C) AND ALIGN THE BASE TO SAME DIRECTION WITH THE SHADE, AND TIGHTEN THE BASE WITH WASHERS (D) AND NUT (E) AND USING SPANNER PROVIDED.
4. INSERT THE PLUG INTO AN OULET AND TURN ON DIMMER SWITCH.

ENJOY YOUR LAMP!!

**Use Max 15WX2 LED bulbs
(bulbs included)**



***** THIS LED LIGHT PROVIDES LOW MAINTENANCE SERVICE WITH NO BULBS TO CHANGE.*****

** TO REDUCE THE RISK OF ELECTRIC SHOCK, ALWAYS UNPLUG FROM THE ELECTRICAL OUTLET BEFORE INSTALLATION.*

** THIS FIXTURE IS SUITABLE FOR DRY LOCATION ONLY.*

** THIS FIXTURE SHOULD ONLY BE CLEANED WITH A SOFT LINT FREE CLOTH DAMPLED WITH WATER. DO NOT USE ANY CHEMICAL OR ABUSIVE CLEANER AS THEY MAY DAMAGE THE SURFACE OF THE PRODUCTS.*

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY AND EASILY INSERTED. DO NOT ATTEMPT TO ALTER THE PLUG.

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.