

ASSEMBLY INSTRUCTIONS


ITEM NO: LA-8040DK

CAREFULLY PLACE ALL PARTS ON A SMOOTH SURFACE AND LAY THEM UP PER THE SKETCH BELOW.

1. INSERT HARP (B) ONTO SADDLE OF THE BODY AND SOCKET PART (A).
2. PUT SHADE (C) ONTO HARP (B) AND TIGHTEN WITH CLIP (D) AND FINIAL (E).
3. INSTALL RECOMMENDED BULB (NOT INCLUDED IN THIS PACKAGE).

***** 1 OUTLET PORT AND 2 USB CHARGING PORTS PROVIDED! *****

INSERT THE PLUG INTO AN OUTLET AND ENJOY YOUR LAMP!!



**Use Max 100W type A bulb
(bulbs not included)**

** TO REDUCE THE RISK OF ELECTRIC SHOCK, ALWAYS UNPLUG FROM THE ELECTRICAL OUTLET BEFORE INSTALLATION.*

** THIS FIXTURE IS SUITABLE FOR DRY LOCATION ONLY.*

** THIS FIXTURE SHOULD ONLY BE CLEANED WITH A SOFT LINT FREE CLOTH DAMPLED WITH WATER. DO NOT USE ANY CHEMICAL OR ABUSIVE CLEANER AS THEY MAY DAMAGE THE SURFACE OF THE PRODUCTS.*

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.