
## 308-43 GINGER 1LT LARGE (BLACK) PENDANT INSTALLATION INSTRUCTIONS



FIGURE-0<sup>2</sup>

## WARNING


DISCONNECT POWER BEFORE RE-LAMPING OR WIRING THE FIXTURE READ ALL INSTRUCTIONS COMPLETELY BEFORE STARTING INSTALLATION.



Page 1 of 3

THE FIXTURE, PROPERTY AND/OR PERSON(S)!

- Determine the overall desired length of the fixture. Assemble the adjustable stems one at a time onto the fixture leads. Tape the end of the leads to a stiff wire (coat hanger) to aid in pulling them through the stems.
- **3.** Remove the threaded ring from the swivel. Fully thread the swivel onto the nipple. Thread the hex nut onto the nipple and the nipple into the heavy duty strap. Place the canopy over the swivel an against the ceiling. Adjust the nipple so that 1/4" of the threads on the swivel extend beyond the canopy. Tighthen the hex nut against the heavy duty strap. Using the threaded ring, install the canopy.
- 4. Unscrew the ring from the swivel. Let the ring and canopy slide down the stem feed the leads and ground wire up through the swivel and the nipple and into the outlet box.
- 5. Fasten the ground wire to the green or bare coppper wire in the outlet box or the green screw on the heavy duty strap.



WARNING

Never fasten the ground wire to the black or "hot" wire! Failure to follow this instruction could result in serious injury or death!

 Fasten the white fixture lead to the white wire in the Junction Box. Fasten the wires together with an approved fastener (wire nut). Starting about 1" below the fastener, tightly wrap the connection with electrical tape so that the connections seals the end of the fastener.

## WARNING

Make sure that there is no exposed wire or strands that could cause a dangerous short circuit!


- 7. Connect the black fixture lead to the black wire in the Junction Box. Fasten the joined wires as in step 6.
- **8.** Lift the canopy and the swivel ring up the stem. Tighten the ring to hold the canopy in place. (See Figure-02)
- 9. Place the lamp into the socket of the fixture.


**NOTICE:** This fixture is rated for 100w type-A lamp.

## 


DO NOT EXCEED RECOMMENDED WATTAGE!

- 10. Install the glass diffuser onto the fixture fasten using ball nuts.
- 11. Restore power to the circuit breaker or fuse box.









1	R-VJ38B-HRD	MOUNTING HARDWARE
2	R-VJ38B-CPY	CANOPY
3	R-VJ38B-CAC	SOCKET COVER
4	R-VJ38B-ESK	SOCKET
5	R-VJ38B-GLS	GLASS
6	R-VJ38B-STEM	STEM C