



# Grand Piano Lamps

## ← GP10-61

FINISH: Polished Brass  
 HEIGHT: Adjustable 8 1/2" gooseneck  
 CLAMP: Felt-lined, adjusts from 1/2" to 1"  
 BULB: One 40T10 or 60T10  
 SWITCH: On shade  
 SHADE: 10"  
 CORD: 9' Brown

## ← GP10-81

FINISH: Mahogany Bronze  
 HEIGHT: Adjustable 8 1/2" gooseneck  
 CLAMP: Felt-lined, adjusts from 1/2" to 1"  
 BULB: One 40T10 or 60T10  
 SWITCH: On shade  
 SHADE: 10"  
 CORD: 9' Brown

## → GP10-7

FINISH: Black  
 HEIGHT: Adjustable 8 1/2" gooseneck  
 CLAMP: Felt-lined, adjusts from 1/2" to 1"  
 BULB: One 40T10 or 60T10  
 SWITCH: On shade  
 SHADE: 10"  
 CORD: 9' Black



## ← GP14-61

FINISH: Polished Brass  
 HEIGHT: Adjustable 8 1/2" gooseneck  
 CLAMP: Felt-lined, adjusts from 1/2" to 1"  
 BULB: Two 40T10 or 60T10  
 SWITCH: In-line 3" from clamp  
 SHADE: 14"  
 CORD: 9' Brown



## ↑ GP14-7

FINISH: Black  
 HEIGHT: Adjustable 8 1/2" gooseneck  
 CLAMP: Felt-lined, adjusts from 1/2" to 1"  
 BULB: Two 40T10 or 60T10  
 SWITCH: In-line 3" from clamp  
 SHADE: 14"  
 CORD: 9' Black



## ↑ GP14-81

FINISH: Mahogany Bronze  
 HEIGHT: Adjustable 8 1/2" gooseneck  
 CLAMP: Felt-lined, adjusts from 1/2" to 1"  
 BULB: Two 40T10 or 60T10  
 SWITCH: In-line 3" from clamp  
 SHADE: 14"  
 CORD: 9' Brown

