

# 14" Shades



## P14-204

FINISH: Polished Brass  
HEIGHT: Adjusts from 2" to 16"  
BASE: 6¼" round  
BULB: Two 40T10 or 60T10  
SWITCH: On base  
SHADE: 14"  
CORD: 9' Brown



## P14-204-AB

FINISH: Antique Brass  
HEIGHT: Adjusts from 2" to 16"  
BASE: 6¼" round  
BULB: Two 40T10 or 60T10  
SWITCH: On base  
SHADE: 14"  
CORD: 9' Brown




## P14-204-81

FINISH: Mahogany Bronze  
HEIGHT: Adjusts from 2" to 16"  
BASE: 6¼" round  
BULB: Two 40T10 or 60T10  
SWITCH: On base  
SHADE: 14"  
CORD: 9' Brown



## P14-203-81

FINISH: Mahogany Bronze  
HEIGHT: Adjusts from 0" to 12½"  
BASE: 6" Octagon  
BULB: Two 40T10 or 60T10  
SWITCH: On base  
SHADE: 14"  
CORD: 9' Brown



## P14-203-GT

FINISH: Granite  
HEIGHT: Adjusts from 0" to 12½"  
BASE: 6" Octagon  
BULB: Two 40T10 or 60T10  
SWITCH: On base  
SHADE: 14"  
CORD: 9' Brown



## P14-203-AB

FINISH: Antique Brass  
HEIGHT: Adjusts from 0" to 12½"  
BASE: 6" Octagon  
BULB: Two 40T10 or 60T10  
SWITCH: On base  
SHADE: 14"  
CORD: 9' Brown



## P14-203

FINISH: Polished Brass  
HEIGHT: Adjusts from 0" to 12½"  
BASE: 6" Octagon  
BULB: Two 40T10 or 60T10  
SWITCH: On base  
SHADE: 14"  
CORD: 9' Brown